

A=Industriesauger ISC L - 1625 Top	(018577)
B=Industriesauger ISC L - 1625	(018744)
C=Industriesauger ISC L - 1425 Basic	(018676)
D=Industriesauger ISC M - 1625 Safe	(018591)
E=Industriesauger ISC L - 1650 Top	(018584)
F=Industriesauger ISC L - 1625 Premium	(019116)
G=Industriesauger ISC MP-1625 Safe	(019130)
H=Industriesauger ISC L-1425 Top	(019109)
I=Industriesauger ISC L-1625 (CH)	(019154)
J=Industriesauger ISC H-1625 Safe (DK)	(019659)
K=Industriesauger ISC M-1625 Safe (DK)	(019147)
L=Industriesauger ISC L-1625 (DK)	(019178)
M=Industriesauger ISC L-1425	(019925)
N=Industriesauger ISC-ARDL-1425 EW	(011783)
O=Industriesauger ISC ARDL-1425 EWS	(011790)
P=Industriesauger ISC ARDL-1450 EWS	(011806)
Q=Industriesauger ISC ARDL-1425 EWSA	(011813)
R=Industriesauger ISC ARM-1425 EW	(014333)
S=Industriesauger ISC ARMP-1425 EWP	(014340)
T=Industriesauger ISC ARDL-14	(011837)
U=Industriesauger ISC ARDL-1625 EWS	(016467)
V=Industriesauger ISC ARDL-1650 EWS	(016474)
W=Industriesauger ISC ARDL-1625 EW	(016498)
X=Industriesauger ISC ARM-1625 EW	(016481)
Y= Industriesauger ISC H-1625 Safe Plus (EU)	(103150)
Z= Industriesauger ISC L-1625 Top Series 100	(103204)
AA= Industriesauger ISC L-1625 Premium Plus	(100326)
AB= Industriesauger ISC L-1625 Top 240V UK	(110721)

Pos.-Nr. Item-No.	Benennung Name		Typ Typ	Bestell.Nr. Part-No.	PG PG
01+02+05+20+58	Set Unterteil	Set lower housing	A-AB	444970	27
03	Motorgehäuse Ersatz	Motor housing spare	A-AB	444987	23
04+05+06+27+55+56+57	Set Riegel	Set lock bar	A-AB	444994	14
08+11	Set Motorschutzfilter	Set motor protection filter	A-AB	445007	13
09+19	2xElektrode+2xKlemmhülse	2x Electrode + 2x clamping piece	A-AB	441900	09
10+10a	Moosgummi rd. 3,0 m+Vierkantdichtung	foam rubber+square bar sealing	A-AB	442983	14
12	Motorstecker	Motor plug connector	A-AB	417714	12
17	Set Motorgebläse 1200 W	Set motor 1200 W	CH/HM-T	444901	40
17	Set Motorgebläse 1400 W	Set motor 1400 W	A-B/D-G/L-U-AB	444918	41
20	35xSpax-Schraube 3,5x25	35x Spax screw 3,5x25mm	A-AB	441856	09
21	Trägerplatte Ersatz	Carrier plate spare	A-AB	445014	21
22	Deckel Ersatz	Cover housing spare	A-AB	445021	22
23+20	Set Griff	Set handle	A-AB	445038	14
24	Motorsteckdose	Motor plug socket	A-AB	417707	06
26+27+63+20	Set Druckstück+Abstützung	Set pressure piece+brace support	A-AB	444826	12
28+29+30+20	Set Rüttler	Set vibrating magnet	A-AB	445045	34
31+34+5	Set Kontakt Teile	Set contact parts	A-AB	444765	09
32+35+36+20	Set Anschlussleitung	Set power cord	A-C/E/H/M/U-W/Z	444666	22
32+35+36+20	Set Anschlussleitung	Set power cord	D/F/G/R/X/Y/AA	444819	23
32+35+36+20	Set Anschlussleitung	Set power cord	N-Q/S/T	445083	22
32+35+36+20	Set Anschlussleitung (CH)	Set power cord (CH)	I	445687	29
32+35+36+20	Set Anschlussleitung (DK)	Set power cord (DK)	J-L	445694	24
32+35+36+20	Set Anschlussleitung 240V UK	Set power cord 240V UK	AB	467887	21
37+44	Set Frontplatte	Set front plate	A-F/H-R/T-AB	445052	12
37+44	Set Frontplatte Pneumatik	Set front plate pneumatics	G/S	445632	19
38+48+20	Set Elektronik L	Set electronic L	A-C/E/F/H/M/L-Q/T-W/Z/AA/AB	445069	32
38+48+53+20	Set Elektronik M/H	Set electronic M/H	D/J/K/R/X/Y	445144	36
38+48+53+20	Set Elektronik MP	Set electronic MP	G/S	445649	36
40+41+43+45+39	Set Schaltknebel	Set switch knob	A-F/H-R/T-AB	445076	18
40+41+43+45+39	Set Schaltknebel Pneumatik	Set switch knob pneumatics	G/S	445656	14
46+47	Set Maschinensteckdose	Set power tool plug socket	A-F/H/M-R/T-AA	445090	12
46+20	Set Maschinensteckdose	Set power tool plug socket	G/S	444727	16
46+47	Set Maschinensteckdose (CH)	Set power tool plug socket (CH)	I	445670	16
46+20	Set Maschinensteckdose (DK)	Set power tool plug socket (DK)	J-L	445700	21
46+20	Set Maschinensteckdose 240V UK	Set power tool plug socket 240V UK	AB	467894	19
49+50	Faltenfilter FKP 4800 M Advanced	Filter cartridge FKP 4800 M Advanced	A-I/K-M/Z/AB	459257	36
49+50	Faltenfilter FKP 3800 HEP A H14 Advanced	Filter cartridge FKP 3800 HEP A H14 Advanced	J / Y	459264	38
00	Set Aufkleber iPulse/L/M	Set label iPulse/L/M		444857	11
00	Aufkleber "H" Ersatz	"H" label spare	J, Y	444871	13
54	2xLagerbolzen	2x bearing pin	A-AB	443058	07
64+65+66+67+68+69	Set Pneumatik Teile	Set pneumatic parts	G/S	445663	37
62	Diffuser Ersatz	Diffuser spare	D/G/J/K/R/S/X/Y	445380	10

ISC Behälter 25 L					
70/1+71+72+73+74+75+94	Set Behälter 25L	Set Container 25L	A-D/F-O/Q-S/U/W-Y/AB	445151	37
70/1+71+72+73+74+75+94	Set Behälter 25L Metallenkrollen	Set Container 25L metal wheels	Z/AA	461052	37
71	2xVerschluss	2x closing latch	A-D/F-O/Q-S/U/W-AB	443102	09
72+73+74+94	Set Räder 25L	Set wheels 25L	A-D/F-O/Q-S/U/W-AB	445168	18
75	2x Lenkrolle	2x caster wheel	A-D/F-O/Q-S/U/W-Y/AB	443133	14
75	2x Metallenkrolle	2x caster wheel metal	Z/AA	410449	15
92+93	Set Behälterverschluss	Set container stopper	R/S/X	445205	17
95	Zubehöraufnahme Ersatz	Accessory holder spare	A-D/F-O/Q-S/U/W-AB	445113	16

IS/ISC Behälter 50 L					
80+81+82+83+84+85+86+74+75+83a+92+93+8+8/1+8/2	Set Behälter IS 50L	Set container IS 50L	E/P/V	445175	50
8+8/1+8/2	Ablass-Set	Drain set	E/P/V	408958	15
75	2xLenkrolle m. Feststeller	2x caster wheel with arrester	E/P/V	443133	14
82+83+83a+74	Set Räder 50L	Set wheels 50L	E/P/V	445182	21
81+84+85+86	2xVerschluss+2xKniehebel 2xScheibe+2xSchraube	2x closing latch + 2x knee lever + 2x slice + 2x screw	E/P/V	409627	10
87+88	Set Fahrbügel+Federstecker	Set pushing handle+fastener spring	E/P/V	445199	26
92+93	Set Behälterverschluss	Set container stopper		445205	17

IS Behälter 25 L					
siehe ISC 25L	Set Behälter 25L	Set Container 25L		445151	37
71	2xVerschluss	2x closing latch		443102	09
72+73+74	Set Räder 25L	Set wheels 25L		445243	18
75	2x Lenkrolle	2x caster wheel		443133	14
92+93	Set Behälterverschluss	Set container stopper		445205	17

